



**LIST OF SPARES**

Item	Description	Pack	R3838	R3839	R3837	R3981	R3982
			R3836	R3839	R3837	R3981	R3982
1	Motor / Flywheel	1	X7593	X7593	X7593	X7593	X7593
2	Motor Cradle Retainers	Set	X7594	X7594	X7594	X7594	X7594
3	Motor drive shaft and bearings etc	Set	X7595	X7595	X7595	X7595	X7595
4	Cylinder block / Valve gear	Set	X7596	X7609	X7609	X7596	X7609
5	Coupling rods	Set	X7597	X7597	X7597	X7597	X7597
6	Drive gears cover etc	Set	X7598	X7598	X7598	X7598	X7598
7	Loco Wheel Set	Set	X7599	X7599	X7599	X7599	X7599
8	Front pony and screw	Set	X7600	X7600	X7600	X7600	X7600
9	drawbar	1	X7601	X7601	X7601	X7601	X7601
10	Loco chassis bottom and pick ups	1	X7602	X7602	X7602	X7602	X7602
11	Speedo	1	X7603	X7603	X7603	X7603	X7603
12	Tender chassis assy	1	X7604	X7610	X7610	X7610	X7610
13	Tender wheel set	1	X7605	X7605	X7605	X7605	X7605
14	Tender chassis bottom and pick ups	Set	X7606	X7606	X7606	X7606	X7606
15	Loco chassis pick ups	1	X7607	X7607	X7607	X7607	X7607
16	Electrical tender socket	1	X9958	X9958	X9958	X9958	X9958
17	Wires to Tender Plug	1	X6113	X6113	X6113	X6113	X6113
18	PCB socket and blanking plug	1	X7608	X7608	X7608	X7608	X7608
NI	Assy Bag	Pack	X13965	X13965	X13965	X13965	X13965